



Made in Vancouver, Canada


US Patent # D687,740
EU Patent # 001695834-001 to 004

Berlin
europe@bocci.com
www.bocci.com


Vancouver
sales@bocci.com
www.bocci.com

For additional assistance, please contact Bocci:


1 Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable.
Use patience: allow the cable to uncoil completely to avoid kinks.



2 Drill a maximum 9mm (0.35") diameter hole in ceiling material. Pull low voltage house wire through the hole.
Note: There **MUST** be adequate backing, not just the drywall. This low voltage wire will run to a remote mounted power supply.




3 Thread the coaxial cable through the canopy, use a 2mm Allen key to loosen the setscrew in the canopy and gently feed the cable through until you have reached your desired drop length.
Use Allen key to tighten the setscrew to hold the strain relief and secure the coaxial cable at its new length.
Perform a gentle tug test to ensure it is secure.
DO NOT OVERTIGHTEN.




Note: The strain relief is a black plastic collar around the coaxial cable. There is a single slot opening on the side of the strain relief component. It is essential that this opening is oriented at 90 degrees to set screw chamber. There can be no contact between the set screw and the cable.
RISK OF ELECTRIC SHORT!

4 Primary: connect live and neutral power supply leads to supply wiring. Live with Live wire and Neutral with Neutral.
Secondary: Connect (+/-) wires to the coaxial cable using #16 butt splices, provided (stagger the splices).




For multiple pendant installations, ensure that the braided outer wires are all connected to one 12V output wire and all inner insulated wires are connected to the other or a short will occur.
Wires are 1.02mm (18AWG).
Note: Insulated core is positive and braided exterior is negative.

5 The client is responsible to ensure fasteners are attached to a robust structural substrate.
Affix mini-canopy to ceiling surface with fasteners provided. Twist the threaded cover into place.
Turn power to fixture on.



6 Bocci lamps are included. Plug the lamp into the socket. Do not touch the lamp with your bare hands. Ensure power to lamp is working correctly.
Remove the center cap from 28 pendant. Install 28 pendant by sliding the center cap onto the coaxial cable, gently insert the lamp into the pendant, then tighten the center cap connection by hand.
DO NOT OVERTIGHTEN.
Remove the protective film from the center cap after assembly.



Note: when using a dimmer use only low voltage electronic dimmer.

7 Clean fingerprints from surfaces.

